
## POWERBLOCK\*

# POWERBENCH 2.0 CHIN-UP ATTACHMENT ASSEMBLY INSTRUCTION SHEET 1

ITEM NO.	DESCRIPTION	QTY.
1	CHIN-UP EXTENSION	1
2	CHIN-UP GRIP ASSEMBLY	1
3	STEEL HEX HEAD SCREW, M10 X 1.5 MM THREAD,80 mm LONG	2
4	STEEL HEX NUT, M10 X 1.5 mm THREAD	2
5	STEEL WASHER FOR M10 SCREW SIZE	4

#### TOOLS NEEDED: TWO 17 mm WRENCHES.

1. ATTACH AND TIGHTEN CHIN-UP GRIP ASSEMBLY (ITEM 2) TO CHIN-UP EXTENSION (ITEM 1) WITH SUPPLIED HARDWARE.




## POWERBLOCK\*

### POWERBENCH 2.0 CHIN-UP ATTACHMENT ASSEMBLY INSTRUCTION SHEET 2

ITEM NO.	DESCRIPTION	QTY.
1	BENCH	1
2	BENCH FRAME TUBE END CAP	1
3	CHIN-UP ATTACHMENT ASSEMBLY	1
4	CHIN-UP TIGHTENER KNOB	1

- 1.
- REMOVE THE END CAP(ITEM 2) FROM THE BACK PAD TUBE(ITEM 1). PLACE CHIN-UP ATTACHMENT ASSEMBLY(ITEM 3) IN THE BACK PAD TUBE(ITEM 1). TIGHTEN THE CHIN-UP TIGHTENER KNOB(ITEM 4). 2.
- 3.
- MAKE SURE YOUR BENCH IS SET IN THE CORRECT POSITION BEFORE USING THIS **ATTACHMENT**



#### CAUTION:

- 1. USE THE PRODUCT ON A FLAT SURFACE.
- USER TOTAL LOAD WEIGHT CAPACITY 250 lb. 2.
- TIGHTEN THE CHIN-UP TIGHTENER KNOB BEFORE USING.